
## ENCLOSURE FOR NBN (NATIONAL BROADBAND NETWORK) NBNBOX, NBNPPBOX, NBNBOXBRACKET, NBNPPBOXBRACKET

# L<sup>¬</sup> legrand<sup>®</sup>



## Mounting of NBN Co. Devices:

A "mounting surface template", as defined by NBN Co. in their specifications, is fixed to the top-right corner of the enclosure.

The mounting surface template is 565mm H x 325mm W and dedicated to the installation of NBN Co. devices only.

1. Unscrew mounting surface template from within the enclosure and mount the NBN Co. devices. (See above example figure a) Please refer to NBN Co. "Residential Preparation and Installation Guide: SDUs and MDUs" for more detailed information about layout and spacing between equipment

(available on: www.nbnco.com.au).

- 2. Use Ø20 or 25mm cable entries (top/bottom/back of enclosures) to get incoming cables inside the NBNBOX/ NBNPPBOX.
- 3. Connect NBN Co. devices as per NBN Co. wiring instructions. A double GPO is provided to power NBN Co. Power Supply Unit (PSU) Enclosure must be earthed.
- 4. Screw mounting surface template back into the enclosure.

## Flush Mounting Installation:

A dedicated bracket is required for installations where the enclosure needs to be recessed into the wall (partial recess only).

NBNBOXBracket: Kit to convert NBNBOX into a flush-mounting enclosure.

NBNPPBOXBracket: Kit to convert NBNPPBOX into a flush-mounting enclosure.

- 1. Cut out wall as per following dimensions: NBNBOX: 710mm H x 390mm W NBNPPBOX: 910mm H x 390mm W
- 2. Slide Bracket over box (from rear of box).
- 3. Position Bracket according to intended recessed depth (75mm or 90mm).
- 4. Screw Bracket to box using the M4 screws provided.
- 5. Insert box and bracket assembly into wall cut-out.
- 6. Screw from the inside of the box (side and top/bottom) towards wall studs.
- 7. Mount NBN Co. devices on mounting surface template (refer to Section 1. See opposite).

## Disclaimers:

The socket outlet (GPO) must be installed by a licenced electrician. This product has no user serviceable parts and no attempt should be made to repair this product. For repair please contact HPM Legrand. For indoor use only. HPM Legrand reserves the right to modify the specification of this product at any time.

## Warranty

HPM Legrand will honour all statutory guarantees that you as a consumer are entitled to rely upon under the Australian Consumer Law against a manufacturer including a guarantee that any products HPM Legrand has manufactured or imported are of acceptable quality.

To make a claim under any statutory guarantee (or other warranty) you should first contact the supplier, contractor or retailer from whom you purchased the products.

#### **Customer Service**

For all Customer Service and Technical Support enquires please call Monday to Friday during business hours.

HPM Legrand Australia 1300 369 777 www.hpmlegrand.com.au

HPM Legrand New Zealand 0800 476 009 www.hpmlegrand.co.nz

ABN: 31 000 102 661