


Connected switch with neutral (with dimmer option)

5 743 30/31/32/33/40/41/42/43




This product is a connected accessory which **requires** you to buy and install the Arteor with Netatmo connected starter pack first.

Pack contents:




5 743 40/41/42/43


Connected switch with neutral
(with dimmer option)



5 743 30/31/32/33



Gateway



Leave home/back
home general control

Characteristics

In default operating mode (on/off), this switch works with the following bulbs:

			LED 		
110-240 VAC 50/60 Hz	2 x 1.5 mm ² 1 x 2.5 mm ²				
240 VAC	Max.	150 W	(*)150 VA	150 VA	150 VA
110 VAC	Max.	75 W	(*)75 VA	75 VA	75 VA

(*) Or 15 bulbs max. For a good light comfort, it is recommended to use bulbs of the same type and the same manufacturer.

In dimmer option operating mode (which can be activated via the App), this switch functions only with dimmable bulbs (identifiable by the logo on packaging).




Before you start: wiring precautions



Do not use: two connected switches to control the same lighting point.


If you plan to install a two-way light switches, read the following precautions:



Connected switch
(with dimmer option)


x 1

AND



x 1
or several


Wireless controls for all control points
(not included in this pack)



Connected switch
(with dimmer option)

x 1

AND



x 1
or several


Mechanical push button
(not included in this pack)

OR

Tip if replacing a two-way switch using a wireless control:

old flush-mounted switch replaced by the wireless control.

Use a **connector**
to connect live wire
and traveller wires
1 and 2.



① Necessary safety precautions

1



Switch OFF the power at the main circuit breaker


OFF

2




Make sure that the power is OFF before continuing with the installation.

② Install the connected switch




Remove the existing switch

② Wire the connected switch



② Wire the connected switch



50 m max.

Option: possibility to manage this switch (with dimmer option) by up to 20 mechanical push buttons (not equipped with locator/indicator light).



Attention, the dimmer must be installed on the lamp side.

— N (neutral) = blue
— L (live) = any except blue and green/yellow

Frequency bands: 2.4 - 2.4835 GHz
Power level: < 100 mW



The connected switch with neutral (with dimmer option) works with standard or dimmable bulbs including LED. LED dimmable bulbs are mandatory for an optimal dimmer usage.



③ **To add a connected product to your connected installation, you should follow the instructions:**

- in the **Legrand Home + Control application** (**Settings/Add a new product** section)
- or consult the user manual on **legrand.fr**



www.legrand.fr/reference/574341

LEGRAND - Pro and Consumer Service - BP 30076
87002 LIMOGES CEDEX FRANCE • www.legrand.com

⚠ Safety instructions

This product should be installed in compliance with installation rules, preferably by a qualified electrician. Incorrect installation and/or incorrect use can lead to risk of electric shock or fire.

Before carrying out the installation, read the instructions and take account of the product's specific mounting location.

Do not open up, dismantle, alter or modify the device except where specifically required to do so by the instructions. All Legrand products must be opened and repaired exclusively by personnel trained and approved by Legrand. Any unauthorised opening or repair completely cancels all liabilities and the rights to replacement and guarantees. Use only Legrand brand accessories.


SIMPLIFIED EU DECLARATION OF CONFORMITY

The undersigned,


Legrand

declares that the radio-electric equipment referred to in these instructions complies with directive 2014/53/EU.

وتثبيتها أولاً Netatmo مع Arteor هذا المنتج هو إكسسوار متصل يتطلب منك شراء حزمة بدء متصلة من نوع




بوابة




عناصر التحكم العامة
لمغادرة المنزل/العودة إلى المنزل

محتويات الحزمة:



5 743 30/31/32/33



5 743 40/41/42/43

مفتاح متصل مع سلك محايد
(مع خيار آلية ضبط شدة الإضاءة)

الخصائص

في وضع التشغيل الافتراضي (التشغيل/إيقاف التشغيل)، يعمل هذا المفتاح مع المصابيح التالية:

		مصباح LED 			
150 أمبير	150 أمبير	150(*) أمبير	150 واط	كحد أقصى	240 فولت تيار متردد
75 أمبير	75 أمبير	75(*) أمبير	75 واط	كحد أقصى	110 فولت تيار متردد

(*) أو 15 مصابيح بحد أقصى. للحصول على مستوى إضاءة مريح، يوصى باستخدام مصابيح من نفس النوع ومن نفس الجهة المصنعة.


في وضع تشغيل خيار آلية ضبط شدة الإضاءة (والذي يمكن تنشيطه عبر التطبيق)، يعمل هذا المفتاح فقط مع المصابيح القابلة لتغيير شدة الإضاءة (يمكن التعرف عليها من خلال الشعار الموجود على العلبة).



لا تستخدم: مفاتيح متصلين للتحكم في نقطة الإضاءة نفسها.




إذا كنت تخطط لتثبيت مفاتيح للتحكم في مصباح واحد، فافقراً الاحتياطات التالية:




واحد

مفتاح متصل
(مع خيار آلية ضبط شدة الإضاءة)



واحد

Connected switch
(with dimmer option)




و

واحد
أو مجموعة

وحدات تحكم لاسلكية لجميع نقاط التحكم
(غير مضمنة في هذه الحزمة)

أو




و

واحد
أو مجموعة

زر ضغط ميكانيكي
(غير مضمن في هذه الحزمة)

تلميح: في حالة استبدال أحد مفاتيحي التحكم في مصباح واحد باستخدام وحدة تحكم لاسلكية: يتم استبدال المفتاح القديم المركب بشكل مستوي على السطح بواسطة وحدة التحكم اللاسلكية.

استخدم موصلاً لتوصيل السلك
المتصل بالكهرباء والأسلاك الحاملة
للجهد الكهربائي 1 و 2.



① احتياطات السلامة الضرورية

تأكد من إيقاف تشغيل الطاقة قبل متابعة التركيب.



2

قم بإيقاف تشغيل الطاقة عند قاطع الدائرة الرئيسي


1




إيقاف التشغيل

2 قم بتوصيل أسلاك المفتاح المتصل

التحكم من خلال مفتاح واحد




2 قم بتركيب المفتاح المتصل



قم بإزالة المفتاح الموجود

2 قم بتوصيل أسلاك المفتاح المتصل



نطاقات التردد: 2.4 - 2.4835 جيجا هرتز
مستوى الطاقة: > 100 ملي واط

N (محايد) = أزرق

L (موصل بالكهرباء) = أي سلك

باستثناء الأزرق والأخضر/الأصفر



يعمل المفتاح المتصل مع السلك المحايد (مع خيار آلية ضبط شدة الإضاءة) مع مصابيح قياسية أو قابلة لضبط شدة الإضاءة بما في ذلك مصباح LED. تعد مصابيح LED القابلة لضبط شدة الإضاءة إلزامية للوصول إلى الاستخدام الأمثل لآلية ضبط شدة الإضاءة.



③ لإضافة منتج متصل إلى التركيب المتصل الخاص بك، يجب عليك اتباع الإرشادات:

- في صفحة **Legrand** الرئيسية + تطبيق التحكم (قسم الإعدادات/إضافة منت جديد)
- أو مراجعة دليل المستخدم في **legrand.fr**



www.legrand.fr/reference/574341

LEGRAND - خدمة المتخصصين والعملاء - BP 30076
87002 LIMOGES CEDEX FRANCE • www.legrand.com

إرشادات الأمان: ⚠

يجب تركيب هذا المنتج طبقاً لقواعد التركيب ويفضل أن يقوم بالتركيب كهربائي مؤهل. فقد يؤدي التركيب الخاطئ و/أو الاستخدام الخاطئ إلى مخاطر التعرض لصدمة كهربائية أو نشوب حريق. اقرأ النشرة قبل التركيب، وأفرد مكاناً لتركيب المنتج خاصاً به. لا تفتح أو تفك أو تعدّل أو تحوّر المنتج ما لم يُنشر إلى ذلك بشكل محدد في النشرة. فكل منتجات Legrand يجب فتحها وإصلاحها حصراً من قبل فنيين مدربين ومؤهلين لدى Legrand. وكل فتح أو إصلاح غير مسموح به يُبطل المسؤوليات وحقوق الاستبدال والضمانات.
لا تستخدم سوى إكسسورات من ماركة Legrand حصراً.

SIMPLIFIED EU DECLARATION OF CONFORMITY

The undersigned,

Legrand

declares that the radio-electric equipment referred to in these instructions
complies with directive 2014/53/EU.