Arteor™
with NETATMO

SMART HOME MADE EASY

Contents

L1 legrand

Arteor™
with NETATMO
## SMART HOME MADE EASY

INSTALLATION COMPONENTS

A smart home installation consists of wired products, which can be installed as new or retrofitted as a replacement for existing switches and powerpoints. Wireless switches can then be paired with wired products as shown in this table.

WIRED PRODUCTS

Gateway

Smart Light Switch

Smart Dimmer Switch

Smart Shutter/ Blind Switch

Smart Single Powerpoint

Smart Lighting Micromodule

WIRELESS SWITCHES

Wireless master switch

Night/Day wireless switch

Wireless switch

Shutter/Blind wireless switch

)))) All the products communicate by means of Zigbee radio (2.4 GHz waveband). **Advantage: a dynamic mesh network!**

1 START THE INSTALLATION

ARTEOR WITH NETATMO STARTER KIT

- 1 Smart Light Switch
- 1 Smart Single Powerpoint
- 1 Wireless Master Switch
- 1 Gateway

2 EXTEND THE INSTALLATION

EXTENSION KIT

ARTEOR WITH NETATMO EXTENSION KIT

- 1 Smart Dimmer Switch
- 1 Smart Single Powerpoint
- 1 Wireless Switch

AND/OR

SMART WIRED PRODUCTS

Smart Light Switch

Smart Dimmer Switch

Smart Shutter/ Blind Switch

Smart Single Powerpoint

Smart Lighting Micromodule

+

WIRELESS SWITCHES

Wireless master switch

Night/Day wireless switch

Wireless switch

Shutter/Blind wireless switch

INSTALLATION
## COMPONENTS

STARTER KIT

WIRED PRODUCTS

CONNECTED GATEWAY

Install the gateway **close to an internet router** to optimise the Wi-Fi signal reception. The gateway then communicates with individual switches and sockets using Zigbee radio.

Just one gateway is needed per dwelling.
It can control up to **100 wired and wireless products**.

Can **replace an** existing power outlet: same wiring, same mounting centres.

The gateway is sold in the starter kit or basic kit and cannot be sold separately.

Gateway establishes connection between Router & Arteor with Netatmo products

Unique setup code affixed to the product in order to use the Apple HomeKit app

491-00-681

LED indicator for the installation and power indicator (can be activated in the Home + Control app)

Wi-Fi
ROUTER

WIRELESS MASTER SWITCH

Extra-slim, attached to the wall with the adhesive strips provided. It can be repositioned.

Is installed **near the entrance door** to control Home/Away scenarios involving lights, shutters and power outlets.

Sold both in the starter kit and individually, to be added if the house has more than one entrance. Customised scenarios should be identical on all the master switches.

Scenarios should be configured in the Home + Control app.

CR 2032 - 3V button battery supplied
Standby power: 8 years

Home scenario which can be configured in the Home + Control app.

LED indicator for installation. Low battery indicator (red burst flash)

Away scenario which can be configured in the Home + Control app.

SMART LIGHT SWITCH

Can replace an existing switch, with the same wiring and mounting centres.

Controls all types of conventional and dimmable bulbs, from 5W to 300W: LED, halogen, and compact fluorescent.

Supplied with a load stabilising capacitor, which should be wired up as close as possible to the load. This limits flickering during operation.

SMART DIMMER SWITCH

Can **replace an existing switch**:
same wiring, same mounting centres. No need for neutral (N) wire.

Controls all types of conventional and dimmable bulbs, from **5 to 300 W**: LED, halogen, compact fluorescent.

Always use **dimmable LEDs**.

The dimmer option can be activated from the Home + Control app.

Supplied with a **load stabilising capacitor** which should be wired up as close as possible to a lamp. This is vital to ensure smooth lighting operation, especially for dimming, whatever the type of bulb connected.

Switch-off: quick press. Dimming: press & hold

Optional illuminated switch: LED can be activated from the Home + Control app

100% lighting: quick press.
Dimming: press & hold

Load stabilising capacitor to ensure optimum operation of dimmable lamps.
Only one load stabilising capacitor is sufficient for all the lamps on the switched lighting circuit

SMART LIGHTING MICROMODULE

To be installed near or **directly on the light source.**
Used to provide connected lighting.

Controlled by one or more wireless switches and/or conventional pushbuttons when replacing a remote switch.

For all types of bulbs **up to 300 W:**
LED, halogen, compact fluorescent.

LED indicator for installation

Dimensions (with fixing lugs): 52x40x20mm

INSTALLATION COMPONENTS

legrand

SMART SHUTTER/BLIND SWITCH

Can **replace an existing switch**:
same wiring, same mounting centres.

Compatible with **all wired shutter motors** with electronic or mechanical end stop.

- Up
- Stop
  LED indicator
  for installation
- Down

- Completely raise or lower the shutter:
  quick press
- Adjust shutter height:
  hold down and then release

SMART SINGLE POWERPOINT – 10A

Can **replace an existing powerpoint**:
same wiring, same mounting centres.

The Smart Powerpoint can measure the instantaneous and total power consumption. It is compatible with all electrical appliances, especially with large household appliances.

**Extra built-in protection** in case of overloads of more than 10A.

LED indicator for installation.
Optional illuminated indicator, can be activated from the Home + Control app

NIGHT/DAY WIRELESS SWITCH

Extra-slim, attached to the wall with the adhesive strips provided. It can be repositioned.
Used to **create scenarios** involving lights, shutters and powerpoints at the time people wake up and go to sleep.

Scenarios should be configured in the Home + Control app.

CR 2032 - 3V button battery supplied.
Standby power: 8 years

Wake Up scenario which can be configured in the Home + Control app.

LED indicator for installation.
Low battery indicator (red burst flash)

Sleep scenario which can be configured in the Home + Control app.

WIRELESS SWITCH

Extra-slim, attached to the wall with the adhesive strips provided. It can be repositioned.

Controls smart light or dimmer switches, micromodules and smart powerpoints.

CR 2032 - 3V button battery supplied.
Standby power: 8 years

Switch-off: quick press
Dimming: press & hold
(only available with smart dimmer switch configurations)

LED indicator
for installation.
Low battery indicator
(red burst flash)

100% lighting: quick press.
Dimming: press & hold
(only available with smart dimmer switch configurations)

WIRELESS SHUTTER/BLIND SWITCH

Extra-slim, attached to the wall with the adhesive strips provided. It can be repositioned.

Controls smart shutter/blind switches and can **centralise** control of several shutters.

CR 2032 - 3V button battery supplied.
Standby power: 8 years

- Up
- Stop
- LED indicator for installation.
  Low battery indicator (red burst flash)
- Down

- Fully raise or lower the shutter:
  quick press
- Adjust shutter height:
  hold down and then release

Li legrand®

CREATE A TWO-WAY SWITCH FOR NEW OR RETROFIT INSTALLS

SOLUTION 1

Smart dimmer switch

Wireless switch

CREATE A SWITCHED POWER OUTLET FOR NEW OR RETROFIT WORK

Wireless switch

Smart single powerpoint – 10A

Wireless switch

SOLUTION 2

Smart lighting micromodule

Wireless switch

CENTRALISE SHUTTER/BLIND CONTROL

CREATE SEVERAL CONNECTED CONTROL POINTS

NEW-BUILD

Wireless switch

RETROFIT
(replacing a remote switch)

Existing wired pushbuttons

Connected lighting micromodule

Wireless switch

Connected lighting micromodule

Existing wired pushbutton

Centralise all shutters in the house
Shutter/Blind wireless switch

Centralise the shutters in the living room
Shutter/Blind wireless switch

Smart Shutter/Blind Switch

CHILD'S BEDROOM

PARENTS' BEDROOM

Smart Shutter/Blind Switch

KITCHEN

LIVING ROOM

Llegrand

Smart Dimmer Switch

Smart single powerpoint 10A

Shutter/Blind wireless switch

Below are some examples of secnarios which can be created in the Home + Control app and activated with a single touch. The installed wired products control lights, lamps, electrical appliances and shutters/blinds.

''LEAVE'' SCENARIO

Wireless master switch located by the entrance door.
Pressing the **bottom of the button** activates the scenario, which can be customised to suit users' needs in the Home + Control app.

- **Switches off all ceiling and wall lights**
- **Switches off all lamps and standard lamps**
- **Closes the shutters in the living room**

BATHROOM
CHILD'S BEDROOM
PARENTS' BEDROOM
KITCHEN
CORRIDOR
LIVING ROOM

''ARRIVE'' SCENARIO

Wireless master switch located by the entrance door.
Pressing the **top of the button** activates the scenario, which can be customised to suit users' needs in the Home + Control app.

- **Switches on the lights in the corridor**
- **Switches on the lights and standard lamp in the living room**

BATHROOM
CHILD'S BEDROOM
PARENTS' BEDROOM
KITCHEN
CORRIDOR
LIVING ROOM

''SLEEP'' SCENARIO

Night/Day wireless switch located in the parents' bedroom.
Pressing the **bottom of the button** activates the scenario, which can be customised to suit users' needs in the Home + Control app.

- **Switches off all ceiling and wall lights**
- **Switches off all lamps and standard lamps**
- **Switches on the lights in the parents' bedroom**
- **Closes all the shutters**

BATHROOM
CHILD'S BEDROOM
PARENTS' BEDROOM
KITCHEN
CORRIDOR
LIVING ROOM

''WAKE UP'' SCENARIO

Night/Day wireless switch located in the parents' bedroom.
Pressing the **top of the button** activates the scenario, which can be customised to suit users' needs in the Home + Control app.

- **Switches on the lights in the kitchen and bathroom**
- **Switches on the standard lamp in the living room**
- **Opens the shutters in the bedrooms**

BATHROOM
CHILD'S BEDROOM
PARENTS' BEDROOM
KITCHEN
CORRIDOR
LIVING ROOM

WIRING DIAGRAMS

GATEWAY
240V a.c.

Wi-Fi
ROUTER

The gateway must be installed close to the router where it can pick up a good Wi-Fi signal.

SMART LIGHT SWITCH
5W min, 300W max, with neutral

1 way

SMART DIMMER SWITCH
5W min, 300W max, without neutral

A load stabilising capacitor is important to ensure optimum operation of dimmable lamps.
Just one is sufficient for all the lamps on the switched lighting circuit. Supplied with the smart dimmer switch and smart light switch

SMART SINGLE POWERPOINT
10A 240V a.c. 2400W max

SMART SHUTTER/BLIND SWITCH
1 x 500VA - For all types of shutter motor with electronic or mechanical end stop

SMART LIGHTING MICROMODULE
240V a.c. – 300W max – All loads

STARTING SETUP AND PAIRING

CREATE THE NETWORK

1 After installing and connecting up the wired products, **turn the power back on**. The LEDs on the products **light up with a steady red light.**

Gateway | Smart light switch | Smart dimmer switch | Smart single powerpoint 10A | Smart shutter/ blind switch | Smart lighting micromodule

**2** Remove the protective tab from the battery to supply power to the **wireless master switch.**

3 **Press briefly** in the centre of the wireless master switch in order to activate it. Its LED **flashes green then goes off.**

The LED on the **Gateway power outlet** also goes off.

4 1-Move the wireless master switch close to the **Gateway** and **press the centre** of the switch until its LED briefly lights up green.
2-**Release hold**. The LED goes off.
3-The gateway power outlet LED changes to a steady green light.

One after another, the LEDs on the other wired products change to a **steady green light.**

1 2 3

The network is created.

PAIR WIRELESS SWITCHES

1 After creating the network, you can pair wireless switches to control the connected switches and power points.
Remove the protection tab from the wireless switch you wish to pair, **then go to steps 2, 3 and 4.**
Repeat the same operation with each switch, one after another.

Wireless switch

Shutter/Blind wireless switch

The **Wireless Master Switch** and **Night/Day** wireless switches are paired via the Home + Control app.

For more information, please visit legrand.com or use the links below.

Wireless master switch:
https://faq.homecontrol.eliotbylegrand.com/question/829

Night/Day wireless switch:
https://faq.homecontrol.eliotbylegrand.com/question/828

2 Press briefly.

3 **Keep your finger pressed** on the top or bottom of the wireless switch, then **tap 3 times** on the product you wish to control.

4 1-The LEDs on both products **flash quickly** (blue) then light up **briefly** (steady blue).

2-The LED on the wireless switch **goes off**, the one on the wired product **reverts to green.**

TAP TAP TAP

They have been paired successfully.
Repeat the same operation with each wireless switch, one after another.

> Possible combinations of wireless switches and wired products: see page 2

IMPORTANT: Once installation is completed, leave the starter kit user guide and product manuals with your customer. The user guide contains a unique code to configure the Apple HomeKit app.

# HOME + CONTROL APP:

① DOWNLOAD THE HOME + CONTROL APP

• Prerequisite: a working Wi-Fi router.
• Once you have downloaded the app, follow the step-by-step screens
  to create an account and set up your customer's installation.

If your customer is with you, and they have an iPhone:
download the Home + Control app and set up the installation with their iPhone. This way, you will scan the Apple HomeKit single-use code directly into their iPhone (see next page).

IMPORTANT

If you are working alone: use an Android smartphone.

Do you only have an iPhone or iPad? Then avoid setting up the installation in the Home + Control app because your customer will not be able to scan the HomeKit code on their iPhone.

Home + Control
INSTALL

FREE DOWNLOAD

Download on the App Store

GET IT ON Google Play

Wi-Fi ROUTER

Setup
Ready to start ?
We will now start your installation setup.
If you have wired the products by yourself, please make sure you followed the quick start guide instructions.
Start

② SET UP THE INSTALLATION (continued)

Setup
Well done! Your Gateway Power Outlet is now set up.
Next

4-Click **Next.**
If you are using an iPhone:
Set up the Apple Homekit before going to step 5.

Add Accessory   Cancel
059-17-735
Use the HomeKit Setup Code
Look for the code on the accessory or its packaging and position it in the frame.
Don't Have a Code or Can't Scan?
Learn About Home Accessories

With the iPhone: scan the code on the gateway or on the back of the user manual.

Setup
You will now move from room to room to detect the switches and power outlets of your installation.
Go forward

**5**-Click **Go forward** and move from room to room: the app will automatically detect any installed wired products.

② SET UP THE INSTALLATION

First, hold down the centre of the Wireless master switch until it briefly lights up green.

Setup
Press and hold the center of the master switch until it lights up briefly in green then release.
Next

1-Click **Next.**

Setup
Select a Wi-Fi network.   Refresh
RR04DSI
Guest
Smartphone
Livebox-67d6
Bureau
RR05DSI
Orange-915F
Can't find my network

2-Select the house or router **Wi-Fi network** to connect the gateway power outlet to it.
If you are using an Android smartphone: enter the router password

Setup
Searching for the Gateway Power Outlet ...

3-The gateway connects to the Wi-Fi automatically.

Setup
Name   Outdoor
Bathroom
Kitchen
Living room
Bedroom
Garage
Outdoor   ✓
Toilets
Dining room
Validate

6-Select the type of room you are in and click **Validate.**

Setup
Office
No products in this room yet.
To make them appear on the screen Press the switches around you. Tap three times onto the power outlets and micromodules.

7-**Press** the switch or **tap three times** on the connected power outlets and micromodules installed in the room.

PRESS

OR

TAP TAP TAP

HOME + CONTROL APP:

2 SET UP THE INSTALLATION (continued)

8-Click **Room configuration finished** once all the products have been detected.

9-Click **Continue** to name products.

10-Name the products.

14-Click **Finish installation** once you have completed all rooms.

15-You will now be able to find all rooms and control the lights electrical appliances and shutters/blinds.

11-Once all products are named. Click **Finish.**

12-Click **Go forward** and move to the next room.

13-Click **Go to next room** and enter the room. Repeat **steps 8 to 14.**

3 CHANGE THE LOCATION OF PRODUCTS ROOM BY ROOM

1-Click **Settings.**

2-Select **Manage my home.**

3-Select for example **Light.**

3 **CHANGE THE LOCATION OF PRODUCTS ROOM BY ROOM (continued)**

4 **MAKE THE INSTALLATION AVAILABLE TO YOUR CUSTOMER AND DELETE YOUR ACCESS DETAILS**

4-You can make the **Light** product blink so you can physically identify it.

5-Click here to assign the **Light** product to a room.

1-Click **Manage guests** and follow the step-by-step instructions.

2-Select **your own access details.**

3-Remove them from the list.

The installation setup is still available and will appear in your customer's Home + Control app when they download it.

6-Position the Light product for example in the **Corridor.**

7-Click **Confirm** to confirm.

Continue in the same way to allocate each product to a room. Example: the **Appliance** and **Light micromodule** products have been assigned to the **Living room**.

NB: You can rename rooms and appliances using the same procedure if you wish.

SHARE THE HOME + CONTROL APP BETWEEN SEVERAL USERS

CONTROL YOUR MAIN HOME AND YOUR SECOND HOME FROM THE HOME + CONTROL APP

1-Click **Manage guests.**

2-Click **Share access to your home with other users** and follow the step-by-step instructions.

Go to the list of homes[1] and click on the home you wish to control

[1] **Android:** settings, at the top of the screen
iPhone: in the centre, at the top of the home screen

Connected home
Starter Kit

Must be ordered for any connected installation

Connected home
Extension Kit

Connected home
Connected Products

Step 1: Starter kit for a connected home

AWNSKITWE

Used to control your home remotely (lighting and electrical appliances) using a smartphone via the Home + Control App and/or voice control (via a voice assistant)
Must be ordered for any connected installation
The connected extension kit or individual connected products can be added to the starter kit
2.4 GHz Wi-Fi connection required

Pack	Cat.Nos		Starter Kit
			Used to create a connected installation Includes: - 1 Gateway 240V a.c. Wi-Fi 2.4GHz 802.11 b/g/n Zigbee 2.4GHz to 2.4835GHz Supplied with support frame, coverplate and paint cover - 1 Vertical Smart switch 1 gang 240V a.c. 3 wire min. load 5W Max. load 300W. Compatible with most traditional and LED Lighting loads Zigbee 2.4GHz to 2.4835GHz Supplied with load stabilising capacitor, support frame, coverplate and paint cover - 1 Smart Single Powerpoint (protected against overloads) 240V a.c. 10A Compatible with any electrical appliance or large Household appliance. Measures instantaneous Power and monitors daily and monthly consumption, Plus sends configurable notifications (fault, consumption, etc) Supplied with support frame, coverplate and paint cover. Zigbee 2.4GHz to 2.4835GHz - 1 Wireless master switch with preset scenarios which can be customised in the Home + Control App. Supplied with CR2032 3V battery for power supply and 4 removable stickers for fixing the control on any walls. LED function for low battery indication Supplied with support frame and coverplate Zigbee 2.4GHz to 2.4835GHz
1	AWNSKITWE	☐	White
1	AWNSKITMGN	■	Magnesium
1	AWNSKITALU	■	Aluminium
1	AWNSKITCHP	■	Champagne

| Pack	Cat.Nos		Basic Kit
			Used to create a connected installation, includes: - 1 Gateway 240V a.c. Wi-Fi 2.4GHz 802.11 b/g/n Zigbee 2.4GHz to 2.4835GHz Supplied with support frame, coverplate and paint cover - 1 Wireless master switch with preset scenarios which can be customised in the Home + Control app. Supplied with CR2032 3V battery for power supply and 4 removable stickers for fixing the control on any walls. LED function for low battery indication. Supplied with support frame and coverplate Zigbee 2.4GHz to 2.4835GHz
1	AWNBKITWE	☐	White
1	AWNBKITMGN	■	Magnesium
1	AWNBKITALU	■	Aluminium
1	AWNBKITCHP	■	Champagne

Step 2: Connected extension kit

AWNEKITWE

Used to complete your connected installation, requires prior installation of a starter or basic kit
Connected products can be added to the extension kit

Pack	Cat.Nos		Extension Kit
			Used to create a wireless two-way switch and remotely control your electrical appliances. Includes: - 1 Smart Single Powerpoint 240V a.c. 10A (Protected against overloads). Compatible with any electrical appliance or large household appliance. Measures instantaneous power and monitors daily and monthly consumption, plus sends configurable notifications (fault, consumptions, etc). Zigbee 2.4GHz to 2.4835GHz Supplied with support frame, coverplate and paint cover - 1 wireless switch. Supplied with CR2032 3V battery for power supply and 4 removable stickers for fixing the control on any walls. Zigbee 2.4GHz to 2.4835GHz - 1 Vertical Smart Dimmer Switch 1 Gang 240V a.c. 2 wire (no neutral) Min. load 5W Max. load 300W Compatible with most traditional and LED lighting loads. Supplied with load stabilising capacitor Zigbee 2.4GHz to 2.4835GHz Dimmer mode can be activated in the Home + Control app. Locator LED light at the front can be activated in the Home + Control app. Supplied with support frame, coverplate and paint cover
1	AWNEKITWE	☐	White
1	AWNEKITMGN	■	Magnesium
1	AWNEKITALU	■	Aluminium
1	AWNEKITCHP	■	Champagne

Step 2: Connected products

| AWNVSW1WE | AWNVSW2MGN | AWNHSW3ALU | AWNWSW1WE | 574 243 |

Used to complete your connected installation, requires prior installation of a Starter kit for connected installation

Pack	Cat.Nos		Smart Light Switch
			240V a.c. 3 wire Min. load 5W Max. load 300W Compatible with most traditional and LED Lighting loads Zigbee 2.4GHz to 2.4835GHz Supplied with load stabilising capacitor, support frame, coverplate and paint cover
			Vertical - 1 Gang
1	AWNVSW1WE	☐	White
1	AWNVSW1MGN	■	Magnesium
1	AWNVSW1ALU	■	Aluminium
1	AWNVSW1CHP	■	Champagne
			Vertical - 2 Gang
1	AWNVSW2WE	☐	White
1	AWNVSW2MGN	■	Magnesium
1	AWNVSW2ALU	■	Aluminium
1	AWNVSW2CHP	■	Champagne
			Horizontal - 1 Gang
1	AWNHSW1WE	☐	White
1	AWNHSW1MGN	■	Magnesium
1	AWNHSW1ALU	■	Aluminium
1	AWNHSW1CHP	■	Champagne
			Horizontal - 2 Gang
1	AWNHSW2WE	☐	White
1	AWNHSW2MGN	■	Magnesium
1	AWNHSW2ALU	■	Aluminium
1	AWNHSW2CHP	■	Champagne
			Horizontal - 3 Gang
1	AWNHSW3WE	☐	White
1	AWNHSW3MGN	■	Magnesium
1	AWNHSW3ALU	■	Aluminium
1	AWNHSW3CHP	■	Champagne

Pack	Cat.Nos		Smart Dimmer Switch
			240V a.c. 2 wire (no neutral) Min. load 5W Max. load 300W Compatible with most traditional and LED lighting loads. Supplied with load stabilising capacitor Zigbee 2.4GHz to 2.4835GHz Dimmer mode can be activated in the Home + Control app. Locator LED light at the front can be activated in the Home + Control app. Supplied with support frame, coverplate and paint cover
			Vertical – 1 Gang
1	AWNVDM1WE	☐	White
1	AWNVDM1MGN	■	Magnesium
1	AWNVDM1ALU	■	Aluminium
1	AWNVDM1CHP	■	Champagne
			Horizontal – 1 Gang
1	AWNHDM1WE	☐	White
1	AWNHDM1MGN	■	Magnesium
1	AWNHDM1ALU	■	Aluminium
1	AWNHDM1CHP	■	Champagne

Pack	Cat.Nos		Wireless Switch
			Supplied with CR2032 3V battery and 4 stickers to mount on walls. Zigbee 2.4GHz to 2.4835GHz Supplied complete with support frame and coverplate
1	AWNWSW1WE	☐	White
1	AWNWSW1MGN	■	Magnesium
1	AWNWSW1ALU	■	Aluminium
1	AWNWSW1CHP	■	Champagne

| Pack	Cat.Nos	Connected lighting micromodule
1	574 243	Used to provide connected lighting 300W, with neutral Can be controlled by home + control app push-button switch or wireless switches – paired by tapping the wireless control on the micromodule For installation close to the lighting load Zigbee 2.4GHz to 2.4835GHz

Step 2: Connected products

AWNHGPOWE   AWNVBLIWE   AWNWBLIWE

Used to complete your connected installation, requires prior installation of a Starter or Basic kit

Pack	Cat.Nos		
		Smart Single Powerpoint	
		Used to control electrical appliances remotely	
		Can be paired with one or more wireless switch to create a controlled socket	
		10A 240V a.c.	
		Compatible with any electrical appliance or large household appliance	
		Measures instantaneous power and monitors daily and monthly consumption, plus sends configurable notifications (fault, consumption, etc)	
		Supplied with support frame, coverplate and paint cover	
		Zigbee 2.4GHz to 2.4835GHz	
1	AWNHGPOWE	☐	White
1	AWNHGPOMGN	■	Magnesium
1	AWNHGPOALU	■	Aluminium
1	AWNHGPOCHP	■	Champagne

Pack	Cat.Nos		
		Connected roller shutter switch	
		For local and remote control of a 240V a.c. shutter/blind (raise/lower/stop functions, compatible with shutter/blind with mechanical and electronic stop, not compatible with radio-controlled shutter/blind)	
		Can be paired with one or more shutter/blind wireless switches.	
		Can be installed in place of an existing shutter/blind switch	
		Supplied with support frame, coverplate and paint cover	
		Zigbee 2.4GHz to 2.4835GHz	
1	AWNVBLIWE	☐	White
1	AWNVBLIMGN	■	Magnesium
1	AWNVBLIALU	■	Aluminium
1	AWNVBLICHP	■	Champagne
		Wireless shutter/blind switch	
		Used to control one or more wired shutter/blind switches	
		Pair by tapping on the selected shutter/blind switch(es)	
		Supplied with CR2032 3 V battery for power supply and 4 removable stickers for fixing the control unit on any walls	
		LED function for low battery indication	
		Zigbee 2.4GHz to 2.4835GHz	
1	AWNWBLIWE	☐	White
1	AWNWBLIMGN	■	Magnesium
1	AWNWBLIALU	■	Aluminium
1	AWNWBLICHP	■	Champagne

Step 2: Connected products

AWNWMSWE   AWNWMSMGN   AWNWNDALU   AWNWNDCHP

Used to complete your connected installation, require prior installation of a starter kit for connected installation

Pack	Cat.Nos		
		Wireless master switch	
		Used to add an extra Wireless master switch in a connected installation with multiple entrances	
		Works in the same way as the Wireless master switch included in the starter kit or basic kit	
		Home/Away scenarios can be customised in the Home + Control App	
		Supplied with CR2032 3 V battery for power supply and 4 removable stickers for fixing the control unit on any walls	
		LED function for low battery indication	
		Supplied with support frame, and coverplate paint cover	
		Zigbee 2.4GHz to 2.4835GHz	
1	AWNWMSWE	☐	White
1	AWNWMSMGN	■	Magnesium
1	AWNWMSALU	■	Aluminium
1	AWNWMSCHP	■	Champagne
		Night/Day Wireless switch	
		Used to add 2 extra scenarios to a connected installation	
		Preset Wake up/Sleep scenarios which can be customised in the Home + Control App	
		Supplied with CR2032 3 V battery for power supply and 4 removable stickers for fixing the control unit on any walls.	
		LED function for low battery indication	
		Supplied with support frame, and coverplate.	
		Zigbee 2.4GHz to 2.4835GHz	
1	AWNWNDWE	☐	White
1	AWNWNDMGN	■	Magnesium
1	AWNWNDALU	■	Aluminium
1	AWNWNDCHP	■	Champagne

NOTES

NOTES

NOTES

works with the
Google Assistant

Works with
Apple HomeKit

VOICE ASSISTANTS

Arteor with Netatmo is compatible with the main voice assistants.

WORKS WITH
alexa

COMPATIBILITY

WORKS WITH
legrand®

NETATMO

somfy®

IFTTT

AN OPEN SYSTEM

Arteor with Netatmo is an open system for everyone in the connected home.

L1 legrand®