


Range	Exce	l Life	Arteor				
Cat No	EMUSB2PSAWE EMUSB2PSXWE EMUSB2PSXUG		AR770USB2PSAMWE AR770USB2PSAMMG	AR770USB2PSXMWE AR770USB2PSXMMG			
In-line connector	No	Yes	No	Yes			
Picture							
Installation	In dry wall and wall cavities	With wall box	In dry wall and wall cavities	With wall box			
Output	5V d.c. 4.8A						
Input	230-240V a.c. 50Hz						
Mains connections	Via 'A' and 'N' wires						
Standby power consumption	<0.05W						
Overload protection on output	5.1A ± 0.2A						

USB charging unit installation in the powerpoint for EMUSB2PSAWE/UG, AR770USB2PSAMWE/MG


1 Push USB outlet into extra function hole with arrows facing up as shown




2 Join wires with corresponding mains cables in the 'A' and 'N' terminals of double GPO.

Excel Life USB Charger to be used in conjunction with Excel Life devices. Arteor USB Charger to be used in conjunction with Arteor devices.


USB charger can be assembled with any extra function hole available on powerpoints or switch plates.













Note:


- In application requiring the 3m USB extension lead, it shall not share the same conduit as the 240Va.c. mains wiring in accordance with the Wiring Rules.
- The 3m extension lead is suitable for a standard Ø20mm conduit.
- Do not cover this USB driver with insulating matting or similiar material under any circumstances.





Wall cut-out for standard installation only





Recommended Cut-Out Sizes to Fit Finished Products								
Used on	Α		В		M:= W=!! C==:b= (====)			
	MIN	MAX	MIN	MAX	Min Wall Cavity (mm)			
AR777X	96	100	60	66				
ED777X	76	92	52	58	50			
EDV777X	76	92	54	58				

Disclaimers

- This product must be installed by a licensed electrician.
- For indoor use only.
- Some references are suitable for installation in wall boxes or single brick applications.
- This product should not be installed in areas exposed to constant vibration, temperature fluctuations, or areas of high humidity.
- This product contains no serviceable parts and no attempt should be made to repair this product. If the product is faulty it should be discarded.
- This product has been designed to operate in ambient temperatures 5°C to 40°C.
- The material in this product may vary in colour from batch to batch. Colour matching from one batch to another cannot be guaranteed.
- Electrical installations periodically receive transient over voltages. This product has been designed to minimise the effect of such voltages on connected equipment. It may not give full protection for extreme over voltage transients such as those resulting from a close lighting strike.
- This product has been designed to operate on a nominal supply voltage of 230 240V a.c +/- 6%.
- Cable wiring of different voltage systems, such as Low Voltage and SELV cables, shall not share the same conduit
- This product must be installed and used as per these instructions.
- This product utilises intellectual property in the form of registered designs, trademarks, and/or patents. Such intellectual property remains the property of HPM Legrand in all cases
- HPM Legrand reserves the right to modify the specification of this product at any time.

Warranty

HPM Legrand will honour all statutory guarantees that you as a consumer are entitled to rely upon under the Australian and New Zealand Consumer Laws against a manufacturer including a guarantee that this product is of acceptable quality.

To make a claim under any statutory guarantee you should first contact the supplier, or retailer from whom you purchased this product.

Customer Service

For all Customer Service and Technical Support enquiries please call Monday to Friday during business hours.

HPM Legrand Australia 1300 369 777

www.legrand.com.au

HPM Legrand New Zealand 0800 476 009

www.legrand.co.nz

ABN: 31 000 102 661